


<p>ALTERNATOR</p>  <p>12V</p> <p>Seria 5/6 10-30 Silnik 4Y, 5K, 4P 27060-78003-71</p> <p>SAW/115574</p>	<p>ALTERNATOR</p>  <p>Seria 5/6 Silnik 1DZ, 2Z, 1Z, 2J, 3F, 11Z, 13Z 27060-78305-71</p> <p>SAW/120344</p>
<p>ALTERNATOR</p>  <p>Seria 7/8 10-J35 Silnik 4Y, 5K 27060-78157-71</p> <p>SAW/120420</p>	<p>ALTERNATOR</p>  <p>Seria 5/6 Silnik 4Y, 5K, 4P 27060-78003-71</p> <p>SAW/120424</p>
<p>ALTERNATOR</p>  <p>12V, 50A</p> <p>Seria 7/8 Silnik 1DZ, 2Z, 13Z, 14Z, 15Z 27060-78202-71</p> <p>SAW/115568</p>	<p>ALTERNATOR</p>  <p>Seria 7 Silnik 1FZ 27060-76003-71</p> <p>SAW/115571</p>
<p>ALTERNATOR</p>  <p>12V</p> <p>Seria 5 10-30 Silnik 4P, 4Y 27060-78001-71</p> <p>SAW/115573</p>	<p>ALTERNATOR</p>  <p>12V</p> <p>Seria 7/8 10-J35 Silnik 4Y, 5K 27060-78153-71</p> <p>SAW/115577</p>
<p>ALTERNATOR</p>  <p>12V, 40A</p> <p>Seria 5 10-45 Silnik 1Z, 2J, 3F, 11Z 27060-78301-71</p> <p>SAW/117758</p>	<p>ALTERNATOR</p>  <p>12V, 50A</p> <p>Seria 5/6 10-30 Silnik 1DZ, 2Z, 1Z, 2J, 3F, 11Z, 13Z 27060-78305-71</p> <p>SAW/117759</p>

<p>ALTERNATOR</p>  <p>Seria 7 Silnik G4, GM6-262 27060-30530-71</p> <p>SAW/117760</p>	<p>ALTERNATOR</p>  <p>HC</p> <p>SAW/118372</p>
<p>ALTERNATOR</p>  <p>12V</p> <p>Seria 7/8 10-J35 Silnik 4Y, 5K /27060-78159-71</p> <p>SAW/119820</p>	<p>GEAR SUB-ASSY, DRIVE PLATE & R</p>  <p>ATM</p> <p>Seria 5/6 10-30 Seria 7/8 10-J35 Seria 6 10-30 32101-23030-71</p> <p>SAW/112214</p>
<p>GEAR SUB-ASSY, DRIVE PLATE & R</p>  <p>Seria 5/6/7 ATM Silnik 5K 32101-23810-71</p> <p>SAW/119247</p>	<p>GEAR SUB-ASSY, DRIVE PLATE & R</p>  <p>Seria 6/7/8 ATM Silnik 1DZ, 2Z 32101-22780-71</p> <p>SAW/119248</p>
<p>Regulator napięcia</p>  <p>Seria 7/8 10-J35 Silnik 4Y, 5K 27700-78154-71</p> <p>SAW/115581</p>	<p>STARTER</p>  <p>12V Dry Oryginal</p> <p>Seria 5, 7 Silnik 1FZ 28100-32850-71</p> <p>SAW/113724</p>
<p>STARTER</p>  <p>12V, 9 zębów Dry Oryginal</p> <p>Seria 3/4/5/6/7/8 Silnik 4Y, 3F, 2F, 5R, 4P, 5P, 5K 28100-20551-71</p> <p>SAW/119007</p>	<p>STARTER</p>  <p>12V, 9 zębów Dry</p> <p>Seria 4 10-18 Silnik 3P, 4P 28100-76002-71</p> <p>SAW/113738</p>

<p>STARTER</p>  <p>Seria 5/6/7/8 Silnik 1DZ, 1Z, 2J, 2Z, 11Z, 13Z, 14Z 28100-40291-71</p> <p>SAW/120422</p>	<p>STARTER</p>  <p>Seria 5/6/7/8 10-30 Silnik 1DZ, 2Z, 13Z, 2J, 1Z 28300-23660-71</p> <p>SAW/120423</p>
<p>STARTER</p>  <p>12V Wet</p> <p>Seria 5/6/7/8 10-30 Silnik 1DZ, 1Z, 2Z, 2J 28300-23660-71</p> <p>SAW/113723</p>	<p>STARTER</p>  <p>12V</p> <p>Silnik 1 FZ Seria 5 7 33-A35 28100-32850-71/ORG</p> <p>SAW/120977</p>
<p>STARTER</p>  <p>Wet Oryginal</p> <p>Seria 5 33-45 Silnik 2F, 3F 28100-31970-71</p> <p>SAW/113736</p>	<p>STARTER</p>  <p>Seria 2/4 Silnik 3P, 4P 28100-76016-71</p> <p>SAW/120421</p>
<p>STARTER</p>  <p>12V, 9 zębów Dry Oryginał</p> <p>Seria 3/4/5/6/7/8 Silnik 4Y, 3F, 2F, 5R, 4P, 5P, 5K 28100-20551-71</p> <p>SAW/120793</p>	<p>STARTER</p>  <p>Seria 2/3/4/5/6/7/8 10-J35 Silnik 4Y, 3F, 2F, 5R, 4P, 5P, 5K 28100-20552-71</p> <p>SAW/120131</p>
<p>STARTER</p>  <p>Seria 5/6/7/8 Silnik 4Y, 5K, 4P, G4, GM6 28300-22003-71</p> <p>SAW/120416</p>	<p>STARTER</p>  <p>12V, 9 zębów Wet</p> <p>Seria 5/6/7/8 Silnik 4Y, 5K, 4P, G4, GM6-262</p> <p>SAW/113745</p>

<p>STARTER</p>  <p>Seria 6/7 10-25 Silnik 4Y, 5K 28100-23800-71</p> <p>SAW/120332</p>	<p>STARTER</p>  <p>12V, 11 zębów Dry</p> <p>Seria 5/6/7/8 Silnik 1DZ, 1Z, 2J, 2Z, 11Z, 13Z, 14Z</p> <p>SAW/113722</p>
<p>STARTER</p>  <p>12V, 9 zębów Dry</p> <p>Seria 3/4/5/6/7/8 Silnik 4Y, 3F, 2F, 5R, 4P, 5P, 5K 28100-20551-71</p> <p>SAW/113740</p>	<p>STARTER</p>  <p>Seria 5/6/7 10-25 Silnik 5K 28100-23800-71</p> <p>SAW/113748</p>
<p>GEAR RING</p>  <p>340x304x9,1x133</p> <p>Seria 4/5/6/7/8 10-J35 Silnik 4P, 5R, 5K, 4Y MTM</p> <p>SAW/112393</p>	<p>PLUG</p>  <p>Silnik 4Y, 5K Seria 7/8 10-J35</p> <p>SAW/120647</p>
<p>VOLTAGE REGULATOR</p>  <p>Silnik 4P 27700-22000-71</p> <p>SAW/113695</p>	